IN THE CLAIMS

This listing of claims will replace all prior versions, and listings, of claims in the application:

LISTING OF CLAIMS

1. (Currently Amended) A method for controlling an air conditioner having a multi-compressor comprising the steps of:

pre-storing a compressing capacity of compressors by a temperature difference between a previous room temperature and a desired temperature predetermined preset by a user; and

varying the pre-stored compressing capacity based on a temperature difference between a present room temperature and the desired temperature.

- 2. (Original) The method of claim 1, wherein the pre-stored compressing capacity is varied by selectively operating compressors having the same compressing capacity and compressors having different compressing capacities on the basis of the temperature difference between the present room temperature and the desired temperature.
- 3. (Currently Amended) The method of claim 1, wherein in the step-of varying the pre-stored compressing capacity, the pre-stored compressing capacity is varied on the basis of the temperature difference between the present room temperature and the desired temperature in order to increase a speed that corresponds to a cooling load or {P25105 00041008.DOC}

a heating load.

4. (Currently Amended) The method of claim 1, wherein the step of varying the prestored compressing capacity comprises the steps of:

when the present room temperature reaches a lower limit temperature which is less than the desired temperature predetermined preset by a user under a state that the air conditioner is in a cooling mode, varying the pre-stored compressing capacity into a compressing capacity for maintaining the lower limit temperature and then operating the compressors with the varied compressing capacity; and

operating the compressors with the varied compressing capacity for a
predetermined preset time, then detecting a temperature difference between a present
room temperature and the desired temperature, and then re-varying the varied
compressing capacity into a predetermined preset compressing capacity according to
the detected temperature difference and thereby operating the compressors.

5. (Currently Amended) The method of claim 1, wherein the step of varying the prestored compressing capacity comprises the steps of:

when the present room temperature reaches an upper limit temperature which is more than the desired temperature under a state that the air conditioner is in a heating mode, varying the pre-stored compressing capacity into a compressing capacity for maintaining the upper limit temperature and then operating the compressors with the varied compressing capacity; and

{P25105 00041008.DOC}

operating the compressors with the varied compressing capacity for a
predetermined preset time, then detecting a temperature difference between the
present room temperature and the desired temperature, and then re-varying the varied
compressing capacity into a predetermined preset compressing capacity according to
the detected temperature difference and thereby operating the compressors.

- 6. (Original) The method of claim 1, wherein the compressing capacity is preset according to a ratio between the number of compressors mounted in the air conditioner and a compressing capacity of the compressors.
- 7. (Currently Amended) The method of claim 1 further comprising the steps of: when a compressing capacity corresponding to a present operation mode is equal to a compressing capacity corresponding to a maximum operation mode after varying the compressing capacity of the compressors, operating the compressor in the maximum operation mode;

when the compressing capacity corresponding to the present operation mode is smaller than the compressing capacity corresponding to the maximum operation mode, comparing the compressing capacity corresponding to the present operation mode with a compressing capacity corresponding to a previous operation mode, and as the result, if the compressing capacity corresponding to the present operation mode is smaller than the compressing capacity corresponding to the previous operation mode, operating the compressors in the previous operation mode; and {P25105 00041008.DOC}

when the compressing capacity corresponding to the present operation mode is larger than the compressing capacity corresponding to the previous operation mode, operating the compressors in the present operation mode,

wherein the maximum operation mode is a mode for operating the compressors with a total compressing capacity of the multi-compressor, and the previous mode is a mode for operating the compressors with a pre-stored compressing capacity.

8. (Currently Amended) A method for controlling an air conditioner having a multi-compressor comprising the steps of:

pre-storing a compressing capacity of compressors by a temperature difference between a previous room temperature and a desired temperature;

when a present room temperature reaches a lower limit temperature which is less than a desired temperature predetermined preset by a user under a state that the air conditioner is in a cooling mode, varying the pre-stored compressing capacity into a compressing capacity for maintaining the lower limit temperature and then operating the compressors with the varied compressing capacity; and

operating the compressors with the varied compressing capacity for a predetermined preset time, then detecting a temperature difference between a present room temperature and the desired temperature, and then re-varying the varied compressing capacity into a predetermined preset compressing capacity according to the detected temperature difference and thereby operating the compressors.

9. (Currently Amended) The method of claim 8, wherein the step of re-varying the varied compressing capacity and thereby operating the compressors comprises the steps of:

when a temperature difference between the present room temperature and the desired temperature is more than a first reference value, increasing the varied compressing capacity by a first predetermined preset value;

when the temperature difference between the present room temperature and the desired temperature is less than the first reference value and more than a second reference value, increasing the varied compressing capacity by a second predetermined preset value:

when the temperature difference between the present room temperature and the desired temperature is less than the second reference value and more than a third reference value, maintaining the varied compressing capacity; and

when the temperature difference between the present room temperature and the desired temperature is less than the third reference value, decreasing the varied compressing capacity by the first predetermined preset value.

- 10. (Original) The method of claim 9, wherein the first reference value is 2°, the second reference value is 1°, and the third reference value is 0°.
- 11. (Original) The method of claim 8, wherein the compressing capacity is preset according to a ratio between the number of compressors mounted in the air (P25105 00041008.DOC)

conditioner and a compressing capacity of the compressors.

12. (Currently Amended) The method of claim 8 further comprising the steps of:
when a compressing capacity corresponding to a present operation mode is
equal to a compressing capacity corresponding to a maximum operation mode after
varying the compressing capacity of the compressors, operating the compressor in the
maximum operation mode;

when the compressing capacity corresponding to the present operation mode is smaller than the compressing capacity corresponding to the maximum operation mode, comparing the compressing capacity corresponding to the present operation mode with a compressing capacity corresponding to a previous operation mode, and as the result, if the compressing capacity corresponding to the present operation mode is smaller than the compressing capacity corresponding to the previous operation mode, operating the compressors in the previous operation mode; and

when the compressing capacity corresponding to the present operation mode is larger than the compressing capacity corresponding to the previous operation mode, operating the compressors in the present operation mode.

wherein the maximum operation mode is a mode for operating the compressors with a total compressing capacity of the multi-compressor, and the previous mode is a mode for operating the compressors with a pre-stored compressing capacity.

13. (Currently Amended) A method for controlling an air conditioner having a {P25105 00041008.DOC}

multi-

compressor comprising the steps of:

pre-storing a compressing capacity of compressors by a temperature difference between a previous room temperature and a desired temperature;

when a present room temperature reaches a lower limit temperature which is less than a desired temperature predetermined preset by a user under a state that the air conditioner is in a cooling mode, varying the pre-stored compressing capacity into a compressing capacity for maintaining the lower limit temperature and then operating the compressors with the varied compressing capacity;

operating the compressors with the varied compressing capacity for a
predetermined preset time, then detecting a temperature difference between a present
room temperature and the desired temperature, and then re-varying the varied
compressing capacity into a predetermined preset compressing capacity according to
the detected temperature difference and thereby operating the compressors;

when a compressing capacity corresponding to a present operation mode is equal to a compressing capacity corresponding to a maximum operation mode after varying the compressing capacity of the compressors, operating the compressor in the maximum operation mode;

when the compressing capacity corresponding to the present operation mode is smaller than the compressing capacity corresponding to the maximum operation mode, comparing the compressing capacity corresponding to the present operation mode with a compressing capacity corresponding to a previous operation mode, and as the result, {P25105 00041008.DOC}

if the compressing capacity corresponding to the present operation mode is smaller than the compressing capacity corresponding to the previous operation mode, operating the compressors in the previous operation mode; and

when the compressing capacity corresponding to the present operation mode is larger than the compressing capacity corresponding to the previous operation mode, operating the compressors in the present operation mode,

wherein the maximum operation mode is a mode for operating the compressors with a total compressing capacity of the multi-compressor, and the previous mode is a mode for operating the compressors with a pre-stored compressing capacity.